


FIG. 1



00740873 122100

FIG. 3




FIG. 2





FIG. 4



2025 RELEASED

FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 8

FIG. 9




FIG. 10




FIG. 11





FIG. 12



20250722 14:00:00

FIG. 13




FIG. 14





FIG. 15



001221-22804260

SECRET





FIG. 17



0074087 123100

FIG. 18A

Menu Window

Information:

Warning : Substitute Printing
Print from tray 1 (*A4 / Plain*) for *Letter / Plain*

OK Cancel

FIG. 18B

Menu Window

Information:

Error : Paper Miss match
Load tray 1 : *Letter / Plain*

Select Operation:

> Change Paper ▼

Change Paper
Select tray 1 (*A4 / Plain*) for *Letter / Plain*
Select tray 2 (*Legal / Bond*) for *Letter / Plain*
.
.

OK

Information for Substitute Printing:
◎Need Information ○Not Need Information

FIG. 19





FIG. 20



00740873 122100

FIG. 21




FIG. 22A

Changing paper in tray




FIG. 22B

Compulsory printing by CONTINUE switch





FIG. 23



007227 2207460